

**E39 über 16pol OBD-2:**

|               |           |   |         |                           |
|---------------|-----------|---|---------|---------------------------|
| DME / DDE     | diagnosis | - | Status: | OK                        |
| Inst. Cluster | diagnosis | - | Status: | OK                        |
| SIM           | diagnosis | - | Status: | Module does not respond ! |
| AIRBAG        | diagnosis | - | Status: | OK                        |
| ABS / ASC     | diagnosis | - | Status: | OK                        |
| BC / MID      | diagnosis | - | Status: | Module does not respond ! |
| DWA           | diagnosis | - | Status: | Module does not respond ! |
| ZKE / ZVM     | diagnosis | - | Status: | Module does not respond ! |
| HKL           | diagnosis | - | Status: | OK                        |
| EGS           | diagnosis | - | Status: | Module does not respond ! |
| EWS           | diagnosis | - | Status: | OK                        |
| LCM / CCM     | diagnosis | - | Status: | OK                        |
| PDC           | diagnosis | - | Status: | OK                        |
| CVM           | diagnosis | - | Status: | Module does not respond ! |
| CAS           | diagnosis | - | Status: | Module does not respond ! |
| ZGM           | diagnosis | - | Status: | Module does not respond ! |
| RLS           | diagnosis | - | Status: | Module does not respond ! |

**E39 über 20pol:**

|               |           |   |         |                           |
|---------------|-----------|---|---------|---------------------------|
| DME / DDE     | diagnosis | - | Status: | OK                        |
| Inst. Cluster | diagnosis | - | Status: | OK                        |
| SIM           | diagnosis | - | Status: | Module does not respond ! |
| AIRBAG        | diagnosis | - | Status: | OK                        |
| ABS / ASC     | diagnosis | - | Status: | OK                        |
| BC / MID      | diagnosis | - | Status: | Module does not respond ! |
| DWA           | diagnosis | - | Status: | Module does not respond ! |
| ZKE / ZVM     | diagnosis | - | Status: | Module does not respond ! |
| HKL           | diagnosis | - | Status: | OK                        |
| EGS           | diagnosis | - | Status: | Module does not respond ! |
| EWS           | diagnosis | - | Status: | OK                        |
| LCM / CCM     | diagnosis | - | Status: | OK                        |
| PDC           | diagnosis | - | Status: | OK                        |
| CVM           | diagnosis | - | Status: | Module does not respond ! |
| CAS           | diagnosis | - | Status: | Module does not respond ! |
| ZGM           | diagnosis | - | Status: | Module does not respond ! |
| RLS           | diagnosis | - | Status: | Module does not respond ! |

**E39 BJ99 über 20pol:**

|               |           |   |         |                           |
|---------------|-----------|---|---------|---------------------------|
| DME / DDE     | diagnosis | - | Status: | OK                        |
| Inst. Cluster | diagnosis | - | Status: | OK                        |
| SIM           | diagnosis | - | Status: | Module does not respond ! |
| AIRBAG        | diagnosis | - | Status: | OK                        |
| ABS / ASC     | diagnosis | - | Status: | OK                        |
| BC / MID      | diagnosis | - | Status: | Module does not respond ! |
| DWA           | diagnosis | - | Status: | Module does not respond ! |
| ZKE / ZVM     | diagnosis | - | Status: | OK                        |
| HKL           | diagnosis | - | Status: | OK                        |
| EGS           | diagnosis | - | Status: | OK                        |
| EWS           | diagnosis | - | Status: | OK                        |
| LCM / CCM     | diagnosis | - | Status: | OK                        |

|     |           |   |         |                         |   |
|-----|-----------|---|---------|-------------------------|---|
| PDC | diagnosis | - | Status: | Module does not respond | ! |
| CVM | diagnosis | - | Status: | Module does not respond | ! |
| CAS | diagnosis | - | Status: | Module does not respond | ! |
| ZGM | diagnosis | - | Status: | Module does not respond | ! |
| RLS | diagnosis | - | Status: | Module does not respond | ! |

**E39 520i BJ 11 /97 über 20pol:**

|               |           |   |         |                         |   |
|---------------|-----------|---|---------|-------------------------|---|
| DME / DDE     | diagnosis | - | Status: | OK                      |   |
| Inst. Cluster | diagnosis | - | Status: | OK                      |   |
| SIM           | diagnosis | - | Status: | Module does not respond | ! |
| AIRBAG        | diagnosis | - | Status: | OK                      |   |
| ABS / ASC     | diagnosis | - | Status: | OK                      |   |
| BC / MID      | diagnosis | - | Status: | Module does not respond | ! |
| DWA           | diagnosis | - | Status: | Module does not respond | ! |
| ZKE / ZVM     | diagnosis | - | Status: | OK                      |   |
| HKL           | diagnosis | - | Status: | OK                      |   |
| EGS           | diagnosis | - | Status: | Module does not respond | ! |
| EWS           | diagnosis | - | Status: | OK                      |   |
| LCM / CCM     | diagnosis | - | Status: | OK                      |   |
| PDC           | diagnosis | - | Status: | Module does not respond | ! |
| CVM           | diagnosis | - | Status: | Module does not respond | ! |
| CAS           | diagnosis | - | Status: | Module does not respond | ! |
| ZGM           | diagnosis | - | Status: | Module does not respond | ! |
| RLS           | diagnosis | - | Status: | Module does not respond | ! |

**E39 525TDS BJ 10 /97 über 20pol:**

|               |           |   |         |                         |   |
|---------------|-----------|---|---------|-------------------------|---|
| DME / DDE     | diagnosis | - | Status: | OK                      |   |
| Inst. Cluster | diagnosis | - | Status: | OK                      |   |
| SIM           | diagnosis | - | Status: | Module does not respond | ! |
| AIRBAG        | diagnosis | - | Status: | OK                      |   |
| ABS / ASC     | diagnosis | - | Status: | OK                      |   |
| BC / MID      | diagnosis | - | Status: | OK                      |   |
| DWA           | diagnosis | - | Status: | Module does not respond | ! |
| ZKE / ZVM     | diagnosis | - | Status: | OK                      |   |
| HKL           | diagnosis | - | Status: | OK                      |   |
| EGS           | diagnosis | - | Status: | Module does not respond | ! |
| EWS           | diagnosis | - | Status: | OK                      |   |
| LCM / CCM     | diagnosis | - | Status: | OK                      |   |
| PDC           | diagnosis | - | Status: | Module does not respond | ! |
| CVM           | diagnosis | - | Status: | Module does not respond | ! |
| CAS           | diagnosis | - | Status: | Module does not respond | ! |
| ZGM           | diagnosis | - | Status: | Module does not respond | ! |
| RLS           | diagnosis | - | Status: | Module does not respond | ! |

**E39 525TD BJ 8 /97 über 20pol:**

|               |           |   |         |                         |   |
|---------------|-----------|---|---------|-------------------------|---|
| DME / DDE     | diagnosis | - | Status: | OK                      |   |
| Inst. Cluster | diagnosis | - | Status: | OK                      |   |
| SIM           | diagnosis | - | Status: | Module does not respond | ! |
| AIRBAG        | diagnosis | - | Status: | OK                      |   |
| ABS / ASC     | diagnosis | - | Status: | OK                      |   |
| BC / MID      | diagnosis | - | Status: | OK                      |   |
| DWA           | diagnosis | - | Status: | Module does not respond | ! |

|           |           |   |         |                           |
|-----------|-----------|---|---------|---------------------------|
| ZKE / ZVM | diagnosis | - | Status: | OK                        |
| HKL       | diagnosis | - | Status: | OK                        |
| EGS       | diagnosis | - | Status: | Module does not respond ! |
| EWS       | diagnosis | - | Status: | OK                        |
| LCM / CCM | diagnosis | - | Status: | OK                        |
| PDC       | diagnosis | - | Status: | Module does not respond ! |
| CVM       | diagnosis | - | Status: | Module does not respond ! |
| CAS       | diagnosis | - | Status: | Module does not respond ! |
| ZGM       | diagnosis | - | Status: | Module does not respond ! |
| RLS       | diagnosis | - | Status: | Module does not respond ! |

### E39 530D BJ2000 über 20pol:

|               |           |   |         |                           |
|---------------|-----------|---|---------|---------------------------|
| DME / DDE     | diagnosis | - | Status: | OK                        |
| Inst. Cluster | diagnosis | - | Status: | OK                        |
| SIM           | diagnosis | - | Status: | Module does not respond ! |
| AIRBAG        | diagnosis | - | Status: | OK                        |
| ABS / ASC     | diagnosis | - | Status: | OK                        |
| BC / MID      | diagnosis | - | Status: | Module does not respond ! |
| DWA           | diagnosis | - | Status: | Module does not respond ! |
| ZKE / ZVM     | diagnosis | - | Status: | OK                        |
| HKL           | diagnosis | - | Status: | OK                        |
| EGS           | diagnosis | - | Status: | Module does not respond ! |
| EWS           | diagnosis | - | Status: | OK                        |
| LCM / CCM     | diagnosis | - | Status: | OK                        |
| PDC           | diagnosis | - | Status: | Module does not respond ! |
| CVM           | diagnosis | - | Status: | Module does not respond ! |
| CAS           | diagnosis | - | Status: | Module does not respond ! |
| ZGM           | diagnosis | - | Status: | Module does not respond ! |
| RLS           | diagnosis | - | Status: | Module does not respond ! |

### E39 528iA BJ 08/96 über 20pol:

|               |           |   |         |                           |
|---------------|-----------|---|---------|---------------------------|
| DME / DDE     | diagnosis | - | Status: | OK                        |
| Inst. Cluster | diagnosis | - | Status: | OK                        |
| SIM           | diagnosis | - | Status: | Module does not respond ! |
| AIRBAG        | diagnosis | - | Status: | OK                        |
| ABS / ASC     | diagnosis | - | Status: | OK                        |
| BC / MID      | diagnosis | - | Status: | Module does not respond ! |
| DWA           | diagnosis | - | Status: | Module does not respond ! |
| ZKE / ZVM     | diagnosis | - | Status: | OK                        |
| HKL           | diagnosis | - | Status: | OK                        |
| EGS           | diagnosis | - | Status: | OK                        |
| EWS           | diagnosis | - | Status: | OK                        |
| LCM / CCM     | diagnosis | - | Status: | OK                        |
| PDC           | diagnosis | - | Status: | Module does not respond ! |
| CVM           | diagnosis | - | Status: | Module does not respond ! |
| CAS           | diagnosis | - | Status: | Module does not respond ! |
| ZGM           | diagnosis | - | Status: | Module does not respond ! |
| RLS           | diagnosis | - | Status: | Module does not respond ! |